
Buddy Products


Assembly Instructions



the supplied hex wrench M.


Buddy Products


Assembly Instructions




Position Back
Panel against
bottom and sides
and attach with 8
wood screws L

Position the 2 shelves in place on the positioned Shelf Support Pins on the Side Panels





Align studs and holes in Top Panel with holes and dowels in top of each Side Panel. Push Top Panel down so that Studs are inserted into 1/4-turn insert plugs. Secure Top Panel by turning 1/4-turn Insert Plugs on side panels to tighten.



Attach Handles
D to each door
with 2 screws J